









ALWAYS USE TVS-M GENUINE PARTS



Incase you need any Clarification please contact above Dealer
Or
TVS Motor Company's Area Offices (flip over for addresses)

Or

Toll Free Number: 1800-258-7111 Email: customercare@tvsmotor.com

Disclaimer: TVS Motor Company or any of its officials / Authorized Main dealer / Authorized Dealer do not ask customers for bank / card / wallet details / authentication. In case you face any such claim, please report to the relevant local authorities immediately.



CONTACT AT OUR AREA OFFICES

TAMILNADU-1, 3 & 4

1. TVS Motor Company Limited

V Floor, Gee Gee Universal, No. 2, MC Nichols Road, Chetpet, Chennai - 600 031. Phone: 044-28361651/28361654 Email: AO.Chennai@tvsmotor.com AO.Madurai@tvsmotor.com

TAMILNADU-2

2. TVS Motor Company Limited

No. 10. 2nd floor.

Shree Shanmugapriya Towers, Kannuswamy Street, Behind Hotel Annapoorna, R S Puram, Coimbatore - 641 002. Phone: 0422-4350060/2541035

Email : AO.Coimbatore@tvsmotor.com

KERALA

3. TVS Motor Company Limited

Ambady Towers, Second Floor, Door No. 27/631, A6, Edappally-Pookkattupady Road, Edappally PO., Cochin - 682 024. Phone: 0484-2544578/2556938 Email: AO.Cochin@tysmotor.com

KARNATAKA-1, 2 & GOA

4. TVS Motor Company Limited

No. 600, Anand Surya, 2nd Floor, 15th Cross, 6th Phase, JP Nagar, Opp. BMTC Bus Stop,

Bangalore - 560 078. Phone : 080-26653433

Email : AO.Bangalore@tvsmotor.com AO.Hubli@tvsmotor.com

ANDHRAPRADESH -1 & 2

TVS Motor Company Limited Rukumani Towers. First Floor.

No. 3-11-30, Plot No. 11, Paigha Colony, Behind Anand Theater, Secunderabad - 500 003. Phone: 040-27840590/27844419 Email: AO.Hyderabad@tysmotor.com

AO.Viiavawada@tvsmotor.com

MAHARASHTRA-1 & 2

6. TVS Motor Company Limited

No. 401, 4th Floor, The Chambers, Plot No. 4/12/3, Near Ganapati Chowk, Viman Nagar, Pune - 411 014. Phone: 020-26632111/26632110 Email: Service.pune@tvsmotor.com

MAHARASHTRA-3 & CHATTISGARH

7. TVS Motor Company Limited

No. 502B, 6th Floor, B Wing, Shriram Shyam Towers, Near LIC Square, Sardar, Nagpur - 440 001. Phone: 0712-2569932

Email : Service.Nagpur@tvsmotor.com AO.Raipur@tvsmotor.com

GUJARATH

8. TVS Motor Company Limited

109, Ayna Complex, Opp. Suvarna Villa Bungalows, 100 ft Thaltej Hebbatpur Road, Off: S.G. Highway, Thaltej, Ahmedabad - 380 054. Phone: 079-65443748

Fmail · AO Ahmedahad@tvsmotor.com



MADHYA PRADESH-1 & 2

TVS Motor Company Limited No. 211-212, 2nd Floor.

Chinar Incube Business Centre, Chinar Fortune City, Near Brindhavan Dhaba, Hosangabad Road,

Bhopal - 462 026.

Phone: 0755-2499406/2499306 Email: AO.Bhopal@tvsmotor.com

AO.Indore@tvsmotor.com

RAJASTHAN-1 & 2

10. TVS Motor Company Limited

Plot No. 17-18, 2nd Floor of National Motors Building, Jhotwara Industrial Area,

Jaipur - 302 012.

Phone: 0141-5150901/5150902 Email: AO.Jaipur@tvsmotor.com AO.Udaipur@tvsmotor.com

DELHI & HARYANA

11. TVS Motor Company Limited

D-3 & D-4, 2nd Floor, Sector - 10, Noida, Uttar Pradesh - 201 301

Phone: 011-29834640/29834773 Email: AO.Delhi@tvsmotor.com AO.Harvana@tvsmotor.com

PUNJAB & CHANDIGARH

12. TVS Motor Company Limited

4th Floor, Royal Business Park, Chandigarh Ambala Highway, Zirkapur - 140 603.

Phone: 01762-464777/465777

Email: AO.Chandigarh@tvsmotor.com

UTTAR PRADESH WEST

13. TVS Motor Company Limited D-3 & D-4. 2nd Floor.

Sector - 10, Noida, Uttar Pradesh - 201 301. Phone: 011-29834640/29834773

Email: AO.Upw@tvsmotor.com

UTTAR PRADESH CENTRAL & EAST 14. TVS Motor Company Limited 1st Floor, Cyber Tower, TC-34/V-2.

Vibhuti Khand, Gomti Nagar, Lucknow - 226 010. Phone : 0522-4918300/4918301 Email : AO.Upe@tvsmotor.com AO.Upc@tvsmotor.com

WEST BENGAL

15. TVS Motor Company Limited

Ground Floor & First Floor, 133 A. S. P. Mukherjee Road, Opp. Tollygunge Police Station,

Kolkatta - 700 026.

Phone: 033-24617096/24617092 Email: AO.Kolkatta@tvsmotor.com

BIHAR

16. TVS Motor Company Limited

N-Plaza, Jamal Road, P.S. Kotwali, Patna - 800 001.

Phone: 0612-2200068/2200069 Email: AO BN J@tysmotor.com



ORISSA & JHARKHAND

17. TVS Motor Company Limited

No. 303, 3rd Floor, Creative Plaza, Rasulgarh, Bhubaneshwar - 751 010.

Phone: 0674-2580019

Email: AO.Bhubaneshwar@tvsmotor.com

NORTH EAST STATES

18. TVS Motor Company Limited

147, Udayan, Ganesh Guri, Opp. Punjab National Bank, R G B. Road, Guwahati - 781 005. Phone: 0361-2202030/2202031

Email: AO.Guwahati@tvsmotor.com



Dear Racer,

Thank you for choosing the TVS Apache RTR 160 4V.

The newest member of the Apache family now comes with Fuel Injection for added racing performance. Every feature on the TVS Apache RTR 160 4V is honed on the race track to deliver the best-in-class racing performance.

The Apache Series RTR has a rich racing pedigree with the TVS Apache RTR 160 4V being born from the 6 consecutive Indian National Motorsport Racing Championship winning race machine. As a proud owner of the TVS Apache RTR 160 4V, you are now a part of over two and a half million strong TVS Racing family.

This manual explains the features and operations of your TVS Apache RTR 160 4V. Please read it carefully and follow the instructions to enjoy the ultimate racing experience.

To prolong your journey on the TVS Apache RTR 160 4V, we urge you to get your TVS Apache RTR 160 4V serviced only at TVS Motor Company Dealers or Authorised Dealers.

TVS MOTOR COMPANY LIMITED



Brand Experience

Live the pure performance life.

Since 2005, TVS Apache has been at the helm of performance motorcycling, creating an entirely new breed of racers. And now that you have chosen the ultimate race machine, you are also part of this esteemed legacy. Not just that, you are also standing at the portal to a 360 moto-experience encompassing from out riding your limits at the racetrack to becoming part of a league of riders who share your passion for motorcycling.

Apache Owners Group

Join the league of Apache motor enthusiasts that share your passion for riding. Explore the unchartered, tame every terrain, forge unbreakable bonds, and make unforgettable memories with every journey.

Go on thrilling rides all year round -

Breakfast ride | Overnight ride | Marquee ride | Chapter ride

Apache Racing Experience

If you have the mettle, we have the track. Apache Racing Experience (ARE), a flagship property of TVS Racing & Apache, is the embodiment of our philosophy, "the bikes we race are the bikes we sell." Hone your racing skills and techniques with the INMRC Champion riders from TVS Racing and test the limits of your machine and yourself.

TVS Racing Training School

Founded in 2017, TVS Racing Training School aims at fostering motor sports in India. We believe that all our riders are racers at heart and here, they can unleash that racer and learn the skills under National Champions. And through multiple levels of training, we hope to turn these racing zealots into the podium winners of tomorrow.

Join the AOG community - https://www.tvsapache.com/assets/pdf/AOG-Regulations.pdf and also download the TVS Connect app / https://www.tvsapache.com/aog.aspx





PERFORMANCE GEAR

When you ride your performance machine, you need to have gear that performs too. That's why we have TVS Racing Performance Gear – an entire range of riding gear designed to offer you the ultimate riding experience. With utmost safety and extreme comfort, it lets you take on every terrain and any weather.

With the range of urban wear, you can wear your passion even off track. And the racing DNA woven in is all you need to get your podium look on.

Riding Jackets & Pants | Helmets | Riding Boots | Riding Gloves Polo T-Shirts | Caps | Sunglasses | Backpacks

To know more log on to - https://accessories.tvsmotor.com/performance-gear.aspx



OUR RACING HERITAGE IS NOW YOURS TO TAKE FORWARD

Your TVS Apache is born of the legacy of TVS Racing











NOTICE



Take time to familiarize yourself with your TVS APACHE RTR 160 4V and its performance characteristics.

This Owner's Manual contains a host of useful information. Please take the time to read this manual before you ride your new TVS APACHE RTR 160 4V. Get familiarised with the operation of your motorcycle for maximum safety and pleasure. The better you know your vehicle, the more pleasure you will experience riding your new vehicle. Ensure that anyone else riding your TVS APACHE RTR 160 4V does the same.

All information, illustrations, photographs and specifications contained in this owner's manual are based on the latest product information available at the time of this publication. TVS Motor Company Limited may, however, incorporate modifications or improvements on its vehicles at any time without notice, and therefore, in such events it is possible that the relevant part of the owner's manual does not apply to your vehicle.

Prior permission of TVS Motor Company Limited is required for quoting, copying or reproducing any part of this owner's manual.



Note

Accessories shown in the picture may not be a part of standard equipment. Pictures shown in the manual are of TVS Apache RTR 160 4V with single channel ABS until otherwise specified.

Your motorcycle is provided with always glowing head lamp. The head lamp glows automatically once the engine is started.

Revision 4, Jun 2021

SAFETY INFORMATION



Operating this vehicle safely is an important responsibility of the rider. To help you make decisions on safety, we have provided necessary operating procedure and other information in the owner's manual. This information alerts you on potential hazards that could hurt you or others. Since it is not possible to warn you about all the hazards associated with operating or maintaining the vehicle, you must use your own judgement.

You will find important safety information in following form in the owner's manual as well as the service handbook. These words carry the following connotations:



Warning

Disregarding this message might result in injury to the rider or deadly accidents.



Caution

This message indicates special procedures or precautions to be followed to avoid damage to the vehicle.



Note

This message provides further clarification for clear understanding of any particular information.



RUNNING-IN INFORMATION	0
ANTI-LOCK BRAKING SYSTEM	0
SAFE RIDINGTIPS	0
KNOW YOUR TVS Apache RTR 160 4V	1
RIDING YOUR TVS Apache RTR 160 4V	3
MAINTENANCE	4
WARRANTY AND SERVICES	7
EXPRESS SERVICE	7
EXPERT ON WHEELS	7
PICKUP AND DROP	7
TECHNICAL SPECIFICATIONS	7
GENERAL INFORMATION	8

RUNNING-IN INFORMATION



The first 1000 km is a crucial part of your motorcycle. Proper running-in operation during this period helps in ensuring a **maximum life** and **smooth performance** of your motorcycle.

The reliability and performance of your motorcycle depends on the special care and restrain exercised during the running-in period. It is especially important that you avoid operating the engine in high speed (RPM), which could expose the engine parts to excessive stress. Recommended speed during the running-in is:

Maximum 50 km/h speed upto 750 km (vary the engine speed for better mating of parts).

The first free service at 500 ~ 750 km is most important. During running-in period all the engine components and other parts will have set in. All adjustments to be restored, all fasteners to be tightened. Engine cum transmission oil to be replaced. Timely performance of the first free service will ensure optimum service life and performance from the engine.



Caution

Replacing the engine cum transmission oil during first service is most important for better life of engine. Always use TVS TRU4 FULLY SYNTHETIC oil (SAE 10W30 API-SL, JASO MA2) for better performance and life.

Since your motorcycle is fitted with Evaporative Emission Control System, **the motorcycle should not be laid on the floor during water wash**. Else it may lead to difficulty in starting and improper running of the motorcycle.



Anti-Lock Brake System (ABS)

Your motorcycle is fitted with a **Single Channel Anti-lock Braking System (ABS)** in the front brake system which is designed to prevent skidding and help riders to maintain steering control during emergency-stopping situation in dry or wet roads, loose gravels etc.

How does ABS work?

When a rider applies the front brake continuously, as he detects a dangerous obstacle in dry or wet roads, loose gravels etc. transmits an excessive brake force to the wheel. This excessive force may cause the wheels to stop spinning and leads to lose of road grip. With no firm contact between the tire's contact patch and the road surface, the bike becomes unstable and a crash is imminent.

The slipping wheels on a riding surface results in losing control of whole motorcycle which usually occurs in fractions of a second. Restoring traction while keeping the bike balanced is only a result of luck, or extreme training, as is the case of professional stunt riders who drift. Preventing the wheels from slipping due to excessive braking force compensates losing control and help the rider to maneuver the vehicle and to avoid accidents.


So what the ABS does is actually limiting the braking force exerted by the rider by either squeezing the lever and keep the wheel spinning. Once the imminence of the locking (and therefore skidding) is avoided, the system re-applies the maximum braking force until the next skid is anticipated. By limiting the max force of the braking maneuver, the ABS systems practically allow the riders to use the greatest stopping force possible without locking the front wheel.

How does the ABS understands the wheel locking?

The ABS uses continuous wheel speed monitoring system; wheel speed sensors and toner rings and a Hydraulic Electronic Control Unit (HECU).

During normal operation the ABS works similar to a normal brake. The speed sensor fitted on the front wheel measures the rotational speed of the front wheel, when the wheel speed reduces rapidly i.e. wheel tends to lock, the HECU modulates the pressure in the brake circuit and thereby prevents the wheel from locking.





How the irregular road surface affects the braking?

Humps and irregular surfaces of the road can cause the wheels to lose contact temporarily with the road surface; if this happens the braking force that can be transmitted to road surface is zero.

If the brakes are applied under these condition, the ABS has to reduce the braking force to ensure and maintain the directional stability when the wheels regains its contact with the road surface. At this instant the ABS must reduce the traction, so that the wheels will continue to rotate under all imaginable circumstances, because this is the precondition for ensuring directional stability.

As soon as the actual circumstances arises, the system reacts instantly and adjusts braking force accordingly to achieve optimum braking.

Why does brake lever pulsate during brake application?

Vehicles fitted with ABS uses the conventional brake system during normal operation. But during hard stop the brake lever feels different, i.e., a rapid pulsation in the brake lever; This is absolutely normal.



Warning

The ABS can apply and release the pressure in the brake circuit much faster than that rider can do with brake lever to avoid wheel locking. So there is no need to pump the brake, it requires only continuous application.

Only the front brake of your motorcycle is fitted with ABS system and not the rear brake. Applying rear brake alone can cause wheel skidding just like normal braking system. Always apply both front and rear brake for better performance.



It is not necessary to have this pulsation feel every time the brake is applied. Pulsations are felt only during wheel locking tendency, occurs due to the modulation of pressure in the brake circuit by HECU. Pulsation means that the vehicle is in limit. This pulsation feel also depends on the road condition.

ABS warning lamp

The TVS Apache RTR 160 4V does an automatic self check every time when the ignition switch is turned 'ON'. The ABS warning lamp provided at the speedometer console blinks and informs you that the ABS is under check.



This ABS warning lamp goes 'OFF' once the bike reaches 6 km/h speed and above and the ABS warning lamp blinks whenever the bike speed is less than 6 km/h speed indicating that the ABS is working fine.

If the warning lamp glows continuously even after the bike crossing 6 km/h speed, then the ABS has an error and your bike should be taken to any of our nearest TVS Motor Company Authorised Main dealer / Authorised Dealer.

DO'S AND DON'T'S

Do's

- Check the ABS warning lamp for any warning before driving the vehicle.
- Apply both front and rear brake for better performance.
- Apply continuous brake in ABS mode for better performance. Do not pump.
- Perform the periodic maintenance as per the schedule.
- ABS should be serviced only at TVS Motor Company Authorised Main dealer / Authorised Dealer.

- Carefully remove the front wheel during puncture / tyre replacement to prevent toner ring damage / bend.
- Keep the wheel in such a way that the toner ring is facing upwards.
- Always use recommended brake fluid. Use fresh, clean brake fluid.
- Use only the recommended make, type and size of tyre (ABS tuned with tyre specified by the TVS Motor Company).

Don't's

- Do not use non-standard tyres.
- Do not pump the brakes. Apply the brakes continuously.
- Do not ignore any warning lamp on speedometer.
- Do not adjust the wheel speed sensor air gap your self.
- Do not attempt to correct the toner ring teeth by bending manually or by using any other method.
- Do not use different toner ring.
- Do not insert any metallic parts near wheel speed sensor.
- Do not test the ABS on road!!, but use ABS (it is already tested).



- Do not use non-genuine spares like pads, discs, tyres etc.
- Do not try to service HECU or open to separate parts.
- Do not disengage the ABS by removing the ABS coupler.



Note

Incase of ABS failure, the braking system will work like a non ABS braking system and provides normal stopping distance.

This motorcycle is equipped with ABS (on front wheel) and tubeless tyres. For repair or replacement please contact nearest TVS Motor Company Authorised Main Dealer / Authorised Dealer.

As a general riding practice it is advisable to apply more front brake and less of rear brake.

Use of non-genuine brake pads, tyres, disc etc. leads to poor braking performance and unsafe riding conditions.

Never open HECU on your own, it is a very sensitive part of ABS and needs to be handled only by the trained personnel. Contact your nearest TVS Motor Company Authorised Main Dealer / Authorised Dealer.



Marning

ABS only helps in improving the vehicle control. It is always good to remember not to exceed the physical limits of the vehicle stability. It is rider's responsibility to ride at a suitable speed, while taking care of conditions and road surface. ABS will not compensate for errors in the judgement or improper brake use in the various situation. ABS never eliminates the danger of falling while turning.

Hard braking during sharp cornering on slippery surface may lead to vehicle instability. Under such circumstances gradual braking is recommended.



SAFE RIDING RECOMMENDATIONS

Any two wheeler riding requires some precautions to be taken to ensure the safety of the rider, pillion rider and other road users. These precautions are:

Familiarise yourself with new TVS Apache RTR 160 4V

Riding skill and your mechanical knowledge forms the foundation of safe riding practices. We suggest you to practice riding TVS Apache RTR 160 4V in a low-traffic condition until you are thoroughly familiar with your vehicle and its controls. Remember practice makes you perfect.

Riding apparel

Loose, fancy clothing can be uncomfortable and unsafe when riding a two-wheeler. Choose good quality two wheeler riding apparel.

Know your limits

Ride within the boundaries of your own skill at all times. Knowing these limits and staying within them will help you avoid accidents



Marning

Two wheeler safety starts with wearing a good quality helmet. One of the most serious injuries that can happen is a head injury. Always wear an ISI approved helmet that should fit your head comfortably and securely. You should also have good quality goggles to protect your eyes and help your vision.

To prevent or minimize accident, never consume alcohol or drugs before or during the operation of your vehicle. Even minimal consumption of these will affect the rider's ability to control the vehicle.



Posture

Proper vehicle riding starts with proper posture.

- 1. Keep your elbows relaxed and flexible.
- Sit and adjust yourself on seat so that arms and shoulders are relaxed.
- 3. Look widely instead of gazing at one point.
- 4. Keep the knees close to the fuel tank.

M Warning

One-hand riding is dangerous. Keep both hands firmly on the handle bar and both feet securely on the foot rest. Under no circumstances should both the hands be removed from the handle bar, as it is very dangerous.

Avoid use of mobile phones while riding as it could lead to fatal accident.

Do not downshift the gears in the midst of cornering. Slow down to a safe speed before negotiating a corner. If this is the first time that you are riding a vehicle of this type, we suggest that you practice on a safe, open area to thoroughly familiarise with the operation of the vehicle.

Cornering


When cornering, centrifugal force works in a direction perpendicular to the direction in which the vehicle is moving. Centrifugal force increases in proportion with speed and the radius of the corner.

During cornering, reduce speed so as to reduce the effects of centrifugal force. Avoid abrupt application of brake or sudden steering by all means.

Braking

For safe riding, it is very important to master the braking techniques.

- 1. Close / release the throttle.
- 2. Hold the vehicle upright as you apply the brake.
- 3. Progressive application of brakes is safer.
- 4. Never declutch while braking at higher speeds.
- 5. Apply both the brakes.
- 6. Do not pump the brakes.
- Riding down hills, while cornering and wet roads close throttle and down shift the gear to take advantage of gearbox and engine which acts as an additional brake. This will avoid the loss of control over the vehicle due to over speed.



- If the brake shoes / pads or drum / disc are worn out or if there is water or oil on them, sufficient friction does not develop and brakes do not work well.
- Even when the brake works normally, if the road surface is wet or the tyre surface is worn-out, tyres do not take a firm hold on the surface, increasing the stopping distance.

⚠ Warning

As the vehicle speed increases, the stopping distance also increases progressively. Be sure that, you have sufficient distance between you and the vehicle or obstruction ahead of you. Avoid directing the water jet directly towards brake drum / disc pads during water wash.

Using only the front or rear brake is dangerous and can cause skidding and loss of control. Apply both the brakes together and with great care on a wet road or other slippery surfaces.

Any abrupt braking on slippery or irregular roads can cause loss of rider control.



Approximately 60% braking effect is from front brake. Non-usage of front brake causes poor braking.

ACCESSORY INSTALLATION AND SAFETY TIPS

Use extreme caution while selecting and installing the accessories for your motorcycle.

The addition of **unsuitable accessories can lead to unsafe operating conditions.** Your friendly Dealer will assist you in selecting quality accessories and installing them correctly.

While selecting the accessories, make sure the accessories **should not obstruct lighting, steering, suspension level and ground clearance.** Please ensure that if the tank cover is used, it is not getting en-trapped between fuel tank and fuel tank cap.

Additional electrical equipments and controls should not exceed the specified electrical system load of the vehicle (capacity of battery and magneto).



EMISSION CONTROL

All the TVS vehicles are tested in the factory for optimum fuel efficiency and CO levels. If the vehicle needs any adjustments, please consult nearest TVS Motor Company Authorised Main Dealer / Authorised Dealer

While adequate care is exercised at the factory to ensure that the emissions are within the limits. it is essential for the owner to always maintain the motorcycle in good condition by getting it periodically checked and serviced by TVS Motor Company Authorised Main Dealer / Authorised Dealer so that the emission and fuel consumption levels are maintained as per norms.

Crankcase emission control system

The engine of new TVS Apache RTR 160 4V is equipped with a closed crankcase system to prevent discharging crankcase emissions into the atmosphere. Blow-by gas is returned to the combustion chamber through the air cleaner and the fuel system.

Evaporative Emission Control System

The TVS Apache RTR 160 4V is equipped with an evaporative emission control system which consists of a canister and associated piping. This system prevents the escape of fuel vapors from the fuel tank.

Warning

If there is any abnormal jerk, startability issue are felt in the vehicle or noise due to sudden escape of gas during opening of fuel tank cap, immediately report to the TVS Motor Company Authorised Main Dealer / Authorised Dealer



f Note

Your vehicle is tested and certified for emission which meets BS VI emission norms and is valid for initial 12 months from the date of purchase. Get vour vehicle certified by the Government authorised emission testing station every year (after initial 12 months of usage).




VEHICLE IDENTIFICATION NUMBER

The frame and engine serial numbers are the only means of identifying your vehicle from others of the same model and type. They are also required to assist your Dealer for ordering parts or referring to special information.




Frame serial number is engraved on the right side of the steering head tube as shown in the above figure.



Engine serial number is engraved on the left side crankcase assembly near cylinder block as shown in the above figure.



LOCATION OF PARTS - HANDLE BAR




- Connected instrument cluster
- 2. Ignition cum steering lock
- 3. Master cylinder (front)
- 4. Engine cut off switch
- 5. Rear view mirror R
- 6. Front brake lever
- 7. Throttle grip
- 8. Electric starter switch
- 9. Fuel tank cap
- 10. Horn switch
- 11. Turn signal lamp switch
- 12. High / low beam switch
- 13. Clutch lever

- 14. Rear view mirror L
- 15. Pass by switch




LOCATION OF PARTS - VEHICLE LEFT SIDE



- 1. Wheel hugger rear
- 2. Saree guard
- 3. Rear wheel axle
- . Pillion foot rest L
- . Rider foot rest L
- S. Side stand
- 7. Center stand
- 8. Gear shift lever
- 9. Front wheel axle
- 10. Cover frame L



LOCATION OF PARTS - VEHICLE RIGHT SIDE



- Disc plate front
- 2. Cover toner ring
- Front wheel axle nut
- 4. Wheel speed sensor front
- 5. Toner ring front
- 6. Caliper assembly front
- 7. Location of spark plug
- 3. Gauge oil level
- 9. Rear brake pedal
- 10. Rider foot rest R
- 11. Pillion foot rest R
- 12. Muffler assembly
- 13. Rear wheel axle nut
- 14. Disc plate rear
- 15. Caliper assembly rear
- 16. Cover frame R

17. Location of ram air duct



LOCATION OF PARTS - VEHICLE FRONT & REAR





FRONT

- 1. Turn signal lamp front L
- 2. Head lamp assembly
- 3. Oil cooler
- 1. Crash guard
- . Position lamps
- 6. Turn signal lamp front R

REAR

- I. Turn signal lamp rear R
- 2. Reflex reflector
- 3. Number plate lamp
- . Turn signal lamp rear L
- i. Tail lamp assembly
- Pillion handle

License plates are mandatory accessory will be charged extra



CONTROL KEY

Your TVS Apache RTR 160 4V comes with a pair of identical control keys. These keys are to operate ignition cum steering lock, fuel tank cap and seat lock.

IGNITION CUM STEERING LOCK

The ignition cum steering lock enables and disables the electrical circuit and steering lock. The three positions of the switch are described below.

1. 'OFF' position

All electrical circuits are deactivated. The key can be removed from the lock

2. 'ON' position

All electrical circuits are activated. The instrument cluster and warning lights performs self-diagnostic cycle. Engine can be started. Control key cannot be taken out from the lock.

f Note

When the ignition is turned ON with the engine kill switch ON condition, priming noise of pump may be heard which is absolutely normal.

Frequent switch 'OFF & ON' of ignition to be avoided. After ignition key reset, there may be a delay in start of vehicle for couple of seconds.



3. 'LOCK' position

Your TVS Apache RTR 160 4V steering can be locked in both 'left' and 'right' directions.

Turn the handlebar to the 'left' or 'right'. Press the key 'IN' and rotate it to the 'LOCK' position from 'OFF' position. All the electrical circuits are deactivated and the steering is locked. The control key can be removed from the lock

Insert the control key into the lock and press the key 'IN' and turn it to 'OFF' or 'ON' position to unlock the steering.



\triangle

Warning

Never attempt to move the vehicle when the steering is locked, you may lose balance.



Caution

Leaving the ignition cum steering lock in 'ON' position for a prolonged time will drain the battery when the vehicle is not in use. Switch 'OFF' and take the control key out when the vehicle is not in use. Always lock the steering while parking for safety.




Note

Digital instrument cluster's background illumination, position lamps, tail lamp and number plate lamp glow automatically once the ignition is turned 'ON' without activating any other switch.

DIGITAL INSTRUMENT CLUSTER

Your TVS Apache RTR 160 4V is provided with a fully digital instrument cluster with various features in it.



1. Speedometer Indicates the vehicle speed in kilometer per hour.



2. Fuel gauge

Digital bars indicates the approximate quantity of fuel available in the fuel tank. There are eight bars to indicate the quantity of fuel available in the fuel tank.




All the eight bars will be displayed when the fuel in the tank reaches above 10.4 liters approximately (full tank). When the fuel reaches half tank (6.5 liters approx.) the fuel gauge displays only four bars as shown.



The fuel gauge shows only single bar when the fuel reaches reserve level (3.5 liters approx.).





Low fuel indication (serial No. 4) starts blinking when the fuel reaches to the minimum safe level 2.5 liters approximately. Refill the fuel immediately. Once the fuel level reaches 1.8 liters approximately, no bar will be visible and the low fuel indication (serial No. 4) glows continuously.

If all the fuel level bars in the cluster are blinking contact nearest TVS Motor Company Authorised Main Dealer / Authorised Dealer.



Caution

Before turning the IGNITION key to ON position, ensure the availability of adequate fuel in the tank. That is LOW FUEL INDICATION shall not come ON, before the start of the vehicle.

To avoid dry run of fuel pump, never run vehicle beyond 5 km, after LOW FUEL INDICATION.

3. Turn signal indicator right (→)

Flashes when the 'right' side turn signal indication is activated.

4. Low fuel indication ()

Blinks when the fuel level reaches to minimum safe fuel level. It glows continuously when the fuel comes below minimum safe level

5. Neutral indicator lamp (N)

Glows when the vehicle is in neutral and goes 'OFF' if the gear is shifted from neutral.

6. High beam indicator lamp (≣●)

Glows when the head lamp is activated in high beam.

7. ABS warning lamp ((ABS))

ABS warning lamp blinks when the ignition key is turned 'ON' and speedometer performing self check. This lamp goes 'OFF' once the vehicle reaches 6 km/h speed and above.

1 Note

The ABS warning lamp will blink whenever the vehicle speed is less than 6 km/h which is normal. It also indicates that the ABS is working fine.



If this lamp glows continuously then have your vehicle checked at TVS Motor Company Authorised Main Dealer / Authorised Dealer (refer page No. 04 for more details).

8. Malfunction indicator lamp ()

Malfunction indicator lamp (MIL) ' ' ' ' is activated whenever the ignition is turned ON, till the engine is started. It will go OFF once the engine is started.

If this lamp glows continuously even after starting the engine, it indicates that there may be a error in the system. Immediately contact the nearest TVS Motor Company Authorised Main Dealer or Authorised Dealer.

9. Turn signal indicator left (

Flashes when the 'left' side turn signal indication is activated

10. Digital clock

Indicates the time in 12 hour time format.






If the battery is disconnected and reconnected during service. You may need to reset the time as explained in page No. 24.

11. Shortest time indicator / Odometer / Trip meter 1 & 2 / High speed indicator

The procedure for setting each mode is given in page No 24



11a Shortest time indicator

Shortest time indicator records the minimum time taken so far to reach 60 km/h speed.

You can reset and record new time if required. Set the meter in 'SHORTEST TIME' mode to know the time taken by a rider to reach the specific speed from starting.

LAST RECORD







n Note

Minimum time taken recorded so far to reach 60 km/h speed will be displayed when the ignition is turned 'ON' and the meter is set in 'SHORTESTTIME' mode. You can reset the last time taken and record new time

In shortest time mode, once the vehicle speed reaches 60 km/h the time will stop at the exact point and get recorded if the time is less than the last recorded time

11b. Odometer

Odometer registers the total distance covered by the vehicle in kilometer per hour. The digit after the dot mark denotes one tenth of a kilometer. Set the meter in 'ODO' mode to know the odometer reading.





If you leave the ignition key in 'ON' position and the vehicle is kept without moving for more than 3 minutes. ODO segments starts blinking which is normal. If you notice the ODO segments are blinking while the vehicle is in move. Contact nearest TVS Motor Company Authorised Main Dealer for rectification.

11c. Trip meter 1 & 2

In ODO mode, press mode button once and twice to enter 'TRIP 1' and 'TRIP 2' meters respectively.

Trip meter indicates the trip distance travelled in kilometer. The digit after the dot mark denotes the one tenth of a kilometer.

Provision to measure two different distance 'TRIP 1' or 'TRIP 2' is provided for the users to use as per their convenience.





11d. High speed indicator

High speed indicator records the maximum speed (top speed) achieved by the rider so far. You can reset and record the new speed if required. Refer page No. 24 for resetting the high speed data.

Set the meter in 'HIGH SPEED' mode to know the maximum speed achieved by any user so far.





Whenever the vehicle speed crosses the previous achieved high speed the speedometer flashes the high speed data at the rate of 2 Hz till the speed comes less than 3 km/h. This will happen in all modes except shortest time mode.




Note

Maximum speed recorded so far will be displayed whenever the meter is set in 'HIGH SPEED' mode.

This display will go off automatically once the vehicle starts moving (>3 km/h) and it will continue the normal operation. Max speed recorded will be stored until manual reset. If the high speed is reset, the speed value will be shown as '0'.

12. Shift RPM indicator / 13. Tachometer / 14. Low battery indicator / 15. Service reminder



12 Shift RPM indicator

When the engine reaches the 7000 RPM, red indicator in the digital speedometer glows and indicates the user to shift to next higher gear.



1 Note


By default the shift rpm is set to 7000 RPM.

Shift RPM indicator does not work when the vehicle is in neutral



13 Tachometer

Tachometer indicates the engine speed in multiples of 1000 RPM (Revolutions Per Minute).



14. Low battery indicator

An icon with battery symbol '[- *]' glows when the battery charge is too low. Get the battery checked at TVS Motor Company Authorised Main Dealer / Authorised Dealer

15 Service reminder

If the service is due, whenever the ignition lock is turned 'ON', an icon with spanner symbol ' blinks for 10 seconds after the speedometer's self diagnostic cycle and continues to glow till the vehicle is serviced and reset. Get the vehicle serviced at TVS Motor Company Authorised Main Dealer / Authorised Dealer.



1 Note

Service reminder indicator lamp works only based on the distance covered by the vehicle. This is only a reminder indicator. Customers are advised to keep track and follow the service schedule

MODE AND SET BUTTONS



The Mode (A) and Set (B) buttons are provided to change between various modes and to set the some of the digital display functions of the instrument cluster. The sequence of modes and their selections are explained in detail below.

- 1 ODO
- 2 TRIP 1
- 3. TRIP 2

- 4 HIGH SPEED
- 5. SHORTEST TIME MODE

Setting the digital display

Every press of the Mode button changes the display to other mode. Follow the below procedures to change the display to desired mode.

If ignition is turned OFF when the meter is in 'ODO' or 'TRIP' meters, then the respective meters will be displayed in the next ignition ON. If any other modes other than these were set during ignition OFF, then 'ODO' meter will be displayed in the next ignition ON.

- 1. In 'ODO' mode, press the Mode button once and twice to enter ' \prod_{km} ' and ' \prod_{km} ' meters respectively.
 - To reset any of the trip meter while ensuring the display is in 'TRIP 1' or 'TRIP 2', press and hold the Set button for a few seconds.
- 2. Press the 'Mode' button till the 'H ! 5Pd' display appears to set the 'HIGH SPEED' indicator mode.
 - To reset the high speed recorded, keep the display in 'HIGH SPEED' mode and press the Set button for a few seconds

Mode and set buttons will not work when the vehicle speed exceeds above 10 km/h in the respective modes.



- 4. Press the Mode button till the display changes to ' **99** sr' to set the 'SHORTESTTIME' indicator.
 - To reset the 'LAST RECORD' of the shortest time, press and hold the Set button for few a seconds.
- 5. Press the Mode button once to change the display to 'ODO' mode again.

Digital clock setting

- 1 Press and hold the Mode button till the 'Clock' icon blinks in the display.
- 2. Now, press the Set button so that the hour digit of the clock starts blinking.
- 3. Once again press the Mode button to increase the hours while the hour digits of clock are blinkina.
- 4. Now, press the Set button so that the hours is set and the minute digits of the clock starts blinking.
- 5. Once again press the Mode button to increase the minutes while the minute digits of the clock are blinking.
- 6. Else, press the Set button to set the minutes of the clock and the hour format 'AM' or 'PM' starts blinking on pressing the Set button.




- 7. Now, press the 'Mode' button to change the hour format 'AM' or 'PM'.
- 8. Press the Set button once again to set hour format and to come out from clock setting.



COOLING SYSTEM

TVS Apache RTR 160 4V is designed with an external oil cooler with stone guard arrangement for optimal engine cooling.

The oil cooler is mounted in front of the engine which improves the engine durability and provides better heat management without any compromising the engine performance.



RAM AIR DUCT

TVS Apache RTR 160 4V is designed with a ram air duct on the right side of the fuel tank. This ram air duct throws air exactly above the spark plug while the vehicle in move

The air thrown above the spark plug cools the plug and maintains its temperature in optimum level. Which in-turn results in better heat management without any compromise on the engine performance and improves the engine's durability.





Caution

Care should be taken not to block the ram air duct air passage by cover or any other means. Else it will lead to over heating of engine or seizure.



LED HEAD LAMP

TVS Apache RTR 160 4V comes with a LED head lamp which glows automatically once the ignition is turned 'ON'. Head lamp beam (high/low) can be controlled by pressing the high/low beam switch.




HANDLE BAR LEFT SIDE

1. Horn switch

Press the switch () to blow horn. It is used to attract the attention of other road users in case of danger.

2. Turn signal lamp switch

When the turn signal switch is moved to left ' \leftrightarrows ' or right ' \leftrightarrows ', the corresponding turn signal lamps flashes. To stop flashing, push the switch in.





Failure to switch the turn signal lamp 'ON' or 'OFF' at the right time may lead to an accident.



3. Clutch lever

Press the lever towards grip to disengage the drive. It is used to disengage the clutch while shifting the gears.

4. Pass-by switch

Press the switch to flash the head lamp. It is used to give signal to the vehicles coming from the opposite direction while overtaking other vehicles during day.

The head lamp glows automatically once the engine is started. If the head lamp is glowing in 'Low' beam, on pressing the switch, the head lamp 'High' beam also glows along with the 'Low' beam.

If the head lamp is already glowing in 'High' beam, the pass-by system will not work.

5. Head lamp high / low beam switch

The head lamp glows automatically once the engine is started. Only the head lamp beam (high/low) can be controlled with the beam control switch.

Press the top end of switch for 'High' beam '≣D' and bottom end for 'Low' beam ' ≣D'.



Note

Pass by system will not work if the head lamp is glowing in 'High' beam.

Λ

Warning

Use appropriate head lamp beam 'high / low' as per the traffic and road conditions for your safety and to avoid inconvenience to other riders.

It is strongly recommended to ride the vehicle in 'low' beam during day.



Note


Once the engine is started the head lamp glows automatically. Only head lamp beam (high/low) can be controlled using beam control switch.



HANDLE BAR RIGHT SIDE

1. Electric starter switch

Ensure the transmission is in neutral or else press the clutch lever before engaging the electric starter switch '(₹) '.





Ensure to turn ON the engine cut-off switch before starting the vehicle.

Release the electric starter switch immediately after pressina.

2. Throttle grip

It controls the fuel-air mixture supplied to the engine, which regulates the engine speed. Rotate the throttle grip in counter-clockwise from its idle position to increase the engine speed and vice-versa to reduce.

3 Front brake lever

It controls a hydraulic circuit (ABS) that operates the front brake system. The front brake is applied by pressing the front brake lever gently towards the grip. The brake lamp glows on application of front brake.

4. Engine cut off switch

It is 'X' used to switch off the engine but to keep other DC system active. The ignition circuit is disabled, preventing the engine from being restarted. To restart the engine, return the switch to the 'O' position.



Note

With the ignition switch ON and engine kill is turned ON, priming noise of fuel pump may be heard which is absolutely normal.

Frequent switch 'OFF' & 'ON' of ignition to be avoided to prevent unnecessary run of fuel pump.



FUELTANK# CAP

Flush type fuel tank cap (1) is provided in TVS Apache RTR 160 4V. To open the fuel tank cap, lift the protection lid (2), insert the control key into the lock and turn it in clockwise and lift the cap. Press the cap back to close. Rotate the key anti-clockwise, take out the key and close the lid.

To avoid accumulation of water in the fuel tank, a small drain hole and a pipe is provided in the fuel tank lid cavity so that the water entering through the lid is drained out through a hose.




* The fuel tank is not a measuring instrument and the capacity of the fuel tank may slightly vary from the indicated capacity.

⚠ Warning

Do not smoke while refueling. Do not use cell phones while refueling. Avoid spilling of fuel on the hot engine. Refill petrol in well ventilated area. Switch off the engine while refueling as petrol is highly inflammable. After refilling close the cap properly.

EVAPORATIVE EMISSION CONTROL SYSTEM

This vehicle is fitted with Evaporative Emission Control System (EVAP). If there is any abnormal jerk, startability issue are felt in the vehicle or noise due to sudden escape of gas during opening of fuel tank cap, immediately report to the TVS Motor Company Authorised Main Dealer / Authorised Dealer.





Caution

Never fill fuel beyond the fuel tank inlet (1). Filling above the inlet may result in improper breathing of fuel tank which leads to difficulty in starting as well as improper running of the vehicle.


Whenever refueling the bike fill only the recommended quantity of fuel (10 liter including reserve).

Do not clean the vehicle by laving down on floor, to avoid fuel entry into EVAP system.

GEAR SHIFT LEVER

TVS Apache RTR 160 4V is equipped with a 5 speed constant mesh transmission. Neutral (N) position of the transmission is indicated by the warning light on the speedometer.

To shift the transmission from neutral to first gear. push the gear shift lever down.





Caution

Never shift gears without disengaging the clutch and releasing the throttle. Failure to comply this will lead to rough shift or jerk while shifting the gears. Remember to return to neutral position before restarting the engine.

To change it to the second gear, lift the lever up. Lifting the lever up repeatedly engages all the gears in succession up to the fifth gear.



Gear shift lever position can be set to your convenience. Contact your TVS Motor Company Authorised Main Dealer / Authorised Dealer for setting the gear shift lever position.

GLIDETHROUGHTECHNOLOGY (GTT)

GTT is a feature for low speed urban riding which enables an extremely smooth and controlled ride. With this feature, you can start moving the vehicle with a slow release of the clutch lever, without the throttle operation. This is a convenient feature while riding in heavy traffic. The requirement of the synchronization of the clutch lever and throttle grip is eliminated & engine stalling can be eliminated.

The maximum RPM with GTT feature without throttle

Gear position	GTT RPM
1st Gear	1800 rpm
2nd Gear	1800 rpm
3rd Gear	2000 rpm
4th Gear	2400 rpm
5th Gear	2400 rpm




Caution

GTT is provided in all gears. However, GTT feature is mainly to be used in 1st, 2nd and 3rd gear. It is provided to assist the you to crawl in slow speeds. Care must be taken to control the vehicle if the GTT is used in 4th and 5th gear in traffic condition, as the GTT RPM is kept considerably high in 4th and 5th gear to avoid engine stall.



REAR BRAKE PEDAL

The rear brake pedal operates the rear brake system and it is located adjacent to the right side foot rest. To control the speed of your vehicle close the throttle completely, and gradually press the brake pedal downwards





Rear brake pedal position can be set to your convenience. Contact your TVS Motor Company Authorised Main Dealer / Authorised Dealer for setting the brake pedal position.



A Caution

Independent use of rear or front brake reduces the overall braking efficiency. In extreme conditions braking with only rear or front brake may lock the wheel which would result in skidding or toppling of vehicle.

Braking performance is affected adversely with wet surfaces, loose surfaces and overheating of brake system due to unnecessary continuous application of brakes. For safety, exercise extreme caution while braking and also at turning. Do not accelerate while turning.



STANDS

TVS Apache RTR 160 4V is equipped with a centre (1) and side stand (2).

To place the vehicle on the centre stand, hold the handle bar left grip with left hand and pillion handle with right hand. Place your foot firmly on the centre stand extension (1a) and press with adequate effort. Ensure both the legs of centre stand are touching the ground before placing the vehicle on the stand.

Side stand can be operated by sitting on the vehicle with your left foot by pushing it away from the vehicle to its extreme end.



A

Caution

Do not sit on the vehicle when it is parked on the side stand / centre stand, as your full weight would rest on the vehicle's only support.

Δ

Warning

Park the motorcycle safely on a solid ground. On slopes, engage the first gear and park the vehicle in such a way that the front wheel faces uphill.

Always release the side stand to its full up position before moving the vehicle.



SEAT ASSEMBLY

The seat lock (1) is located at the rear end of the vehicle bellow the tail lamp assembly.

Seat removal

To remove the seat assembly, insert the ignition key into the seat lock and turn it in clockwise direction Pull and take out the seat assembly by lifting it from the rear end and gently tapping it on the front end.





A Caution

Make sure that the seat assembly is locked securely in position after reassembly.

Seat re-assembly

Locate the seat assembly into the frame. Push it little foreword and press at rear end till you hear the 'click' sound



TOOL KIT AND FIRST AID KIT

To assist you in performing certain aspects of periodic maintenance and emergency repairs, a tool kit is supplied along with the vehicle.

A first aid kit is also available along with the tool kit. Both tool kit and first aid kit are located under the seat assembly. To access the tool kit / first aid kit, remove the seat assembly as explained in page No. 35



Tool kit consists of one number each of the following.

- 1. Grip driver
- 2. Bit (+) (-)
- 3. 12 x 14 open end spanner
- 4. Tool bag



Caution

It is recommended to use the tool kit in case of any emergency only. It is always advisable to take your vehicle to TVS Motor Company Authorised Main Dealer / Authorised Dealer



Warning

Do not remove the tool kit and first aid kit from the vehicle. Always ensure to keep them along with the vehicle. Ensure the first aid equipments are changed periodically based on the date of expiry.

COVER FRAME R



Removal

Cover frame R is provided to access the battery and rear disc brake master cylinder. This cover can be opened in the following manner:

- Remove the seat assembly as explained in page No. 35.
- 2. Remove the mounting screws (1), (2), (3) and take out the cover frame.

Re-install

 Locate the lugs of the cover frame at the holes provided on the frame carefully.



- 2. Install and tighten the mounting screws (1), (2) and (3).
- 3. Reassemble the seat assembly.



Caution

Make sure that the cover frame is locked securely in position after installation.

RIDING YOUR TVS Apache RTR 160 4V



PRE RIDE INSPECTION

Check the following items before riding

ITEM	WHAT TO CHECK FOR
Engine cum transmission oil	Availability of oil upto the level (page No. 55)
Fuel	Enough fuel for the planned distance of running
Tyres	Correct pressure (page No. 63)
	Adequate tread depth / No cracks or cuts.
Battery	Proper working of all lamps, horn and pass by switch. Low battery indication
	Battery charge (page No. 50)
Digital instrument cluster	Performing self check / Proper working of ABS warning lamp (page No.19)
Malfunction indicator	Turned OFF after starting the engine (page No. 19)
Steering	Smooth movement / No play or looseness
Throttle	Correct free play of cable / Smooth operation
Clutch	Correct free play of cable (page No. 56) / Smooth and progressive action
Brakes	Availability of brake fluid and proper working of brake (page No. 59)
Wheels	Free rotation
Drive chain	Slackness and lubrication of chain (page No. 66)



Caution

Do not switch 'ON' the ignition without minimum level fuel in tank. It will cause damage to the fuel pump.



STARTING THE ENGINE

As you turn the ignition switch to the 'ON' position, the instrument cluster and the warning lights will go through the self-diagnostic cycle. During this phase, make sure that all the warning lights on the cluster comes on.

The following conditions must be verified before starting the engine.

- \Box The engine cut off switch is in '\(\infty\)' position.
- ☐ The gear is in neutral.
- If gears are engaged, the clutch lever is pulled.

Press the start button without applying the throttle. As soon as the engine starts, release the start button. The engine will not start if the throttle is opened full.



Caution

Do not keep the engine in idling rpm for long.

Do not open excessive throttle when the vehicle is parked. It leads to overheating of engine and damage to the internal components.

SETTING THE VEHICLE IN MOTION

- Press the clutch lever and engage first gear by pressing the gearshift lever down.
- Open the throttle slowly and simultaneously, release the clutch lever gently and gradually. The vehicle starts moving forward.
- 3. As the vehicle picks up speed, shift to the next higher gear by closing the throttle, applying the clutch and lifting the gear shift lever up.
- Release the clutch lever and open the throttle smoothly. Select the required gears in a similar manner.

Using the transmission

The transmission is provided to keep the engine to run smoothly in its normal operating speed range.

The gear ratios have been carefully chosen to meet the characteristics of the engine. The rider should always select the most suitable gear to achieve the necessary speed and pulling power smoothly.



Riding on hills/gradients

When climbing steep hills, the motorcycle may begin to slow down and show lack of power. At this point the rider should shift to a lower gear so that the engine will again be operating in its normal power range. Shift gears rapidly to prevent the motorcycle from losing momentum.

When riding down a hill, the engine may be used as brake by shifting to a lower gear.

STOPPING AND PARKING

- Close the throttle completely and apply both the brakes simultaneously.
- Down shift the gears with clutch lever pressed / disengaged as the road speed decreases. Bring the engine to neutral position just before the vehicle stops.
- 3. Turn the ignition 'OFF'.
- 4. Park the vehicle on a firm, flat surface.
- 5. Lock the steering.

M Warning

Reduce speed to a safe limit before turning/cornering. Do not apply brake while turning/cornering. Do not disengage clutch before braking.

⚠ Warning

Since the engine and exhaust system becomes very hot, make sure to park the vehicle in a place where pedestrians or children are not likely to touch the hot surface. Do not park near dry grass or any other flammable resources which might catch fire.

To avoid deterioration of paint gloss due to ultra violet rays and heat of sunlight, always park your motorcycle in a covered parking.

FUEL RECOMMENDATION

Use only BS VI or unleaded petrol with minimum **RON 91.**

Use recommended fuel additives for longer life of engine components and lower maintenance. Petrol mixed with ethanol will have impact on engine components. Contact your TVS Motor Company Authorised Main Dealer / Authorised Dealer for usage.



Caution

Never mix oil and petrol in the fuel tank. Always fill fuel from reputed and reliable fuel stations.



Use fuel additives in petrol as recommended by the respective manufacturer for low carbon deposition.



CHECKS AND TIPS FOR IMPROVING FUEL **ECONOMY**

Regular checks

Carry out the periodic maintenance checks as specified in this manual (refer page No. 45).

Regular maintenance checks will save fuel ensuring trouble-free, enjoyable and safe riding besides keeping the environment clean.

Spark plug

A dirty or defective spark plug leads to wastage of fuel due to incomplete combustion. Inspect and clean the spark plug if necessary. Visually inspect the spark plug gap. If the gap is found more replace the plug with a new one.

However the spark plug need to be replaced every 12000 kms or 1 year whichever is earlier. Always use recommended spark plug only.



Caution

Do not remove the spark plug when the engine is hot.

Please ensure that the ram air duct is not getting damaged during removal / reassembly of spark plug.



Air cleaner element

A dirty air cleaner element restricts airflow and increases fuel consumption. Replace the element every 12000 kms.

Since paper filter is used in your motorcycle, it is not advised to clean the filter. Replace the filter in case of any abnormalities.

Clutch

Increase in engine speed during acceleration and constant speed running, without increase in vehicle speed indicates clutch slip. The clutch slip will cause high fuel consumption, poor acceleration and overheating of engine.

If the condition persists even after adjusting the clutch lever play, immediately have the clutch checked by TVS Motor Company Authorised Main Dealer / Authorised Dealer.



Caution

Never drive the vehicle with the clutch lever pressed. This will reduce the life of clutch and affect the vehicle performance and fuel economy.

Engine cum transmission oil

Dirty or less engine cum transmission oil increases the friction between various parts of the engine and reduces the engine life, thereby increases fuel consumption.

Regularly inspect the engine cum transmission oil for correct level and top-up if necessary. Get it replaced at regular intervals as per the maintenance schedule. Always use TVS TRU4 FULLY SYNTHETIC oil only (SAE 10W 30 API-SL, JASO MA2).

Fuel leak

If any fuel leak from tank is suspected, tow the vehicle to the nearest TVS Motor Company Authorised Main Dealer / Authorised Dealer.

Tyres

Low tyre pressure has adverse effects on the vehicle. The drag on the vehicle increases resulting in decreased fuel economy. Further more, handling may be affected adversely.



Caution

Do not attempt to do any rectification, as fuel lines are normally pressurized upto 3.5 bar and any activity by any untrained personnel, may lead to un-safe condition. Check the tyre pressure regularly (weekly) and inflate them to the recommended pressure (refer page No. 63). Never use tyres which are worn out beyond the permissible limit.

Chain slackness

Check and ensure drive chain slackness Excess slackness leads to higher fuel consumption (refer page No. 66).

Wheels free movement

Check and ensure the free movement of wheels by rotating the them at least once in a week to avoid wastage of fuel.

Fast starting from rest wastes fuel

A racing start from rest at full throttle will waste fuel and damage the engine. It also creates a potentially dangerous traffic situation. Fuel is wasted whenever the rider suddenly accelerate or apply brake.

Avoid unnecessary idling

While waiting for someone or stopping in signals for long time, if the engine is kept running at idle speed, it causes unnecessary wastage of fuel.

Avoid frequent braking

Anticipate corners and slopes as well as the traffic conditions. Unnecessary and frequent braking reduces the fuel economy.





A Note

Please note that the on-road mileage of TVS Apache RTR 160 4V is dependent on several factors like road condition, quality of fuel, riding speed, operation of clutch and brake, tyre inflation, maintenance / timely servicing of vehicle, load etc., and hence will differ from the mileage given under standard test conditions.



MAINTENANCE SCHEDULE

The maintenance schedule indicates the intervals between periodic services. At the end of each interval, be sure to inspect, check, replace, adjust, lubricate and service as instructed. If the maintenance is not done periodically, it will result in rapid wear and severe damage to the vehicle. If the vehicle is used under high stress conditions such as continuous full throttle operation or is operated in dusty area, certain jobs should be performed more often to ensure reliability of the vehicle. Cylinder head, steering components, suspension, chain and wheel components etc., are key items and require very special and careful servicing. TVS Motor Company Limited strongly recommends that the jobs as per the maintenance schedule be performed by your TVS Motor Company Authorised Main Dealer / Authorised Dealer.

Periodic inspections may reveal one or more parts that may need replacement. Whenever replacing parts on TVS Apache RTR 160 4V, it is recommended that you use only the TVS Motor Company Genuine parts.



Caution

Proper running-in and maintenance are mandatory for making certain that your vehicle is reliable and gives optimum performance at all times. Make sure that the periodic maintenance is performed thoroughly in accordance with the instructions given in this owner's manual.

In more dusty areas, the air filter element required early replacement than the mentioned kilometers to avoid costly damages to the engine.



PERIODIC MAINTENANCE SCHEDULE (months or km whichever occurs earlier)

Item	In free service					After fre	e service	
Service km Period from the date of sale	500 - 750	2nd 2500 - 3000 3 months	3rd 5000 - 6000 6 months	4th 8500 - 9000 9 months	5th 11500 - 12000 12 months	Every 3000 km 3 months	Every 6000 km 6 months	Remarks
Engine cum transmission oil	R	I&T	R	I&T	R	I&T	R	
Oil filter (strainer)	С	-	С	-	С	-	С	
Oil filter (paper filter)	R	-	R	-	R	-	R	
Spark plug ¹	I	-	-	-	R	-	-	Inspect, Clean and adjust if required, Replace every 12000 km
Air cleaner element	I	-	-	-	R	-	-	
SAI hose connections	I	-	-	-	-	-	-	
Tappet clearance	I	-	1 & A	-	1 & A	-	1 & A	Inspect for any noise / starting trouble and adjust if required
Clutch plates	-	-	-	-	-	-	-	Inspect & replace if required every 21000 km
Oil cooler fins	-	-	1 & C	1 & C	1 & C	1 & C	-	
Oil cooler pipes	-	ı		I	I	ı	-	Inspect & replace if required every 15000 km
Engine breather hose	I	I	Ι	I	I	I	-	Replace every 21000 km if required
Engine breather hose	I	1	ı	ı	ı	I	-	Replace every 21000 km if required

Contd...

¹ Replace every 12000 km or 1 year whichever is earlier



Item			In free serv	ice	After free service			
Service km Period from the date of sale	500 - 750	2nd 2500 - 3000 3 months	3rd 5000 - 6000 6 months	4th 8500 - 9000 9 months	5th 11500 - 12000 12 months	Every 3000 km 3 months	Every 6000 km 6 months	Remarks
Fuel filter	I	I	I	I	I	1	-	
Hose fuel with respective clamps	I	I	I	I	I	I	-	Replace every 21000 km if required
Throttle grip	-	-	L	-	L	-	L	Lubricate using grease
Clutch and throttle cable play ²	I, A & L	I, A & L	I, A & L	I, A & L	I, A & L	I, A & L	-	
Steering smooth operation/ play ³	1 & A	-	-	-	C, L & A	-	1	C & L with fresh Bechem premium grade 3 grease every 12000 km
Front fork oil	-	-	-	-	-	-	-	Replace every 18000 km
Front and rear suspension ⁴	- 1	1	I	I	I	I	-	
All fasteners	I & TI	I & TI	I & TI	I & TI	I & TI	I & TI	-	Tighten if necessary
Drive chain**	C, L & A	C, L & A	C, L & A	C, L & A	C, L & A	C, L & A	-	Adjust if necessary
All bulbs, horn and switches	I	ı	ı	I	ı	I	-	Inspect for proper functioning

Inspect for proper operation and adjust play. Lubricate ends using grease.

Contd...

Inspect for smooth steering rotation, steering shake / noise. Adjust the steering if necessary.

⁴ Inspect for smooth and proper function of front and rear suspension. Also inspect for any visual damage and oil leakage.

^{**} Clean the drive chain with dry cloth and apply TRU SPRAY/TRU 4 oil as frequently as every 500 km for better chain life and smooth vehicle running. Check drive chain, rear sprocket and engine sprocket for wear. If any part is worn, replace the same. Always replace the engine sprocket, rear sprocket and chain together.



Item			In free serv	ice		After fre	e service	
Service km Period from the date of sale	1st 500 - 750 1 months	2nd 2500 - 3000 3 months	3rd 5000 - 6000 6 months	4th 8500 - 9000 9 months	5th 11500 - 12000 12 months	Every 3000 km 3 months	Every 6000 km 6 months	Remarks
Head lamp beam	1 & A	1 & A	1 & A	1 & A	1 & A	1 & A	-	
Battery voltage ⁵	I	I	I	I	I	I	-	
Brake effectiveness	I	I	I	I	I	I	-	
Brake pedal shaft	L	L	L	L	L	L	-	Lubricate using TRU4 oil
Brake shoe# / pad wear	I	I	I	I	I	I	-	Replace if necessary
Brake fluid	1&T	1&T	1&T	1&T	1&T	1&T	-	
WSS / toner ring	1 & C	1 & C	1 & C	1 & C	1 & C	1 & C	-	Replace if damaged
WSS cable clamps	ı	ı	I	I	I	I	-	Fix new clamp if found missing
WSS cable	I	I	I	I	I	I	-	Replace if damage
Brake hose / bundy tubes	I	I	I	I	I	-	I	Replace every 30000 km
Bundy tube mounting (all joints)	1 & TI	I & TI	I & TI	I & TI	I & TI	I & TI	-	Inspect for leak
HECU mounting cushions	-	-	I	-	I	-	I	Replace every 30000 km
Toner rings teeth damage	I	I	I	I	I	I	-	Replace if necessary
Malfunction indicator lamp	I	I	ı	ı	I	I	-	Check and resolve the errors using diagnostic tool if the lamp is ON even after starting the engine

Contd....

Recharge if necessary

[#] Applicable for rear drum brake model



Item			In free serv	ice	After free service			
Service km Period from the date of sale		2nd 2500 - 3000 3 months	3rd 5000 - 6000 6 months	4th 8500 - 9000 9 months		Every 3000 km 3 months	Every 6000 km 6 months	Remarks
Master cylinder cups	-	-	-	-	-	-	-	Replace every 21000 km
Wheel freeness	I	I	I	I	I	I	-	
Tyre pressure at cold condition	1 & S	1 & S	1 & S	1 & S	1 & S	1 & S	-	
Ball joint gear shift lever	-	-	L	-	L	-	L	Lubricate using grease
Centre / side stand pivot	L	L	L	L	L	L	-	Lubricate using TRU4 oil
Swing arm bearings	-	-	-	-	-	-	-	C & L with fresh Bechem- premium grade 3 grease every two years
Wheel balancing ⁶	-	-	-	-	1	-	-	
Evaporative emission control system	I	I	I	I	I	I	-	Check for intactness of hoses and canister
Fuel tank assembly**	1 & C	1 & C	1 & C	1 & C	1 & C	1 & C	-	

- R Replace; I Inspect; T Top up; C Clean; A Adjust; DR Drain; L Lubricate; TI Tighten; S Set
- 6 It is advisable to balance the wheels every 1 year or 12000km and also after every tyre puncture or tyre replacement to have better high speed performance.
- ** Check for abnormal vehicle jerk / noise while opening the cap / leak. If found any, contact TVS Motor Company Authorised Main Dealer or Authorised Dealer.



RECOMMENDED LUBRICANTS


APPLICATION	QTY	MANUFACTURER	BRAND
Engine cum transmission oil	1200 ml (after draining) 1400 ml (after disassembly)	TVS Motor Company	TVSTRU4 FULLY SYNTHETIC oil (SAE 10W30 API-SL, JASO MA2)
Front fork oil	242 ± 2.5 cc / leg	-	TRU Fork oil
Disc brake fluid	-	TVS Girling	DOT 3 / DOT 4
Grease	-	Bharat petroleum IOC Bechem	MP Grease no. 3 Servo Gem no. 3 Bechem premium grade 3
Chain lubricant	-	TVS Motor Company	TRU SPRAY



SELF - MAINTENANCE PROCEDURES BATTERY

To ensure better performance and long life of battery, you are requested to follow the steps given bellow:

- 1. Remove the cover frame R (refer page No. 37).
- Check the battery voltage. If the voltage measured is less than 12.4V, charge the battery using TVS Motor Company Limited recommended battery charger only at TVS Motor Company Authorised Main Dealer / Authorised Dealer.
- Apply petroleum gelly to the terminals to avoid corrosion.
- Do not add additional electrical accessories.



Â

Caution

Never check the battery charge by shorting the terminals. Always connect the positive terminal first (red wire) and then negative (black wire) to avoid sparking.

The inversion of the battery wires can damage the battery and the recharging system.

If the motorcycle is to remain unused for a long time (a month or longer), it is advisable to disconnect the battery cables or have the battery removed by skilled personnel.

Recommendations to maintain battery health during prolonged parking conditions

While your vehicle is parked for prolonged duration, battery continues to discharge and if left unattended can get completely discharged. It is recommended to ride the vehicle for minimum 60 km every week to keep the battery in healthy condition This could be at a stretch in one ride or several rides during the week.

The vehicle speed will vary during the ride but an average speed of minimum 30 kmph will be helpful to ensure proper battery charging. Use kick-starting, if available, to conserve battery charge during such period. This is only a recommendation to maintain battery charge and regular service schedules must be followed to maintain your vehicle in good running condition.

The following is recommendations to users regarding battery maintenance before, during and after long storage of battery:

1. Before Storage

- a. Store the battery only after fully charging it
- b. Battery fuse to be disconnected and stored safely. This will reduce the sleep mode current and hence enhance storage life of battery.*



c. Alternatively, battery connecting wires (positive and negative wires) can be disconnected and fasteners can be secured with battery terminals.*

2. During Storage

- a. Store it at room temperature or lower.
- Store the vehicle in the shade and protected from rain and cover the vehicle to prevent rodents from entering and damaging the wires.

3. After Storage

- Connect the wires and fuse, if disconnected earlier, with ignition switch in OFF position*
- b. Start the vehicle by kick starting.

(Above recommendations do not consider storage effects on other systems such as induction and fuel systems and wheels)

^{*} To be done by skilled personnel



Periodic Maintenance of Batteries:

- Keep top of battery clean
- Check cables, clamps, and case for obvious damage or loose connections
- Clean terminals and connectors as necessary Recharge battery if voltage is below 12.4V.

Valve Regulate Lead Acid (VRLA) / Lead Acid batteries are prone to water damage. Any water entry, through vents or otherwise; will result in irreparable damage to the battery or the vehicle.



Warning

Battery develop explosive gases. Keep it away from heat sources. If charging is required the battery must be charged in well ventilated area.

Unusable battery must be disposed in environment friendly manner. Do not discard it with household thrash. Handover the battery to the battery dealers or to a recycle center that accept used battery.

Â

Caution

Never operate the vehicle with discharged battery as it may damage electrical components.


Do not push start the vehicle, use a good battery to start the vehicle.



The electrical components of your motorcycle are protected by four fuses. Out of which three fuses are housed inside a fuse box and located below the seat assembly (at left side). One fuse is located below the cover frame near the battery.

To access the fuses located below the passenger seat:

- 1. Turn 'OFF' the ignition.
- Park the motorcycle on a flat firm surface and remove the seat assembly as explained in page No. 35.
- 3. Open the fuse box lid.







Good Fuse







- 4. The fuse box contains two 15A fuses and one 10A fuse. One 15A fuse is used for ABS system while the other one is used for DC loads. 10A fuse is used for EMS system. Use the 'fuse puller' (A) placed near the fuse box to pull out the blown fuse.
- Replace the blown fuse with a new one with same rating (extra fuses are provided inside the fuse case itself).
- Close the fuse box lid and fix back the seat assembly.

To access the fuse located below cover frame:

- Remove the cover frame R as explained in page No. 37
- 2. Open the fuse holder and pull out the blown fuse (Main fuse 25A).





SPARK PLUG

- 1. Wipe and clean the dust and mud around the spark plug mounting to avoid their entry inside the cylinder.
- 2. Pullout the suppressor cap from spark plug. Remove the spark plug using a plug spanner.

A spark plug with heavy carbon deposits will not produce strong sparks. Hence, only if necessary, remove the carbon deposits from the spark plug with a small wire brush or spark plug cleaning tool.

Inspect the spark plug electrodes (A) and (B) for any corrosion. If found any replace the spark plug with a new one





- Replace the blown fuse with a new one with the same rating (extra fuse (A) is provided in the fuse holder itself)
- 4. Turn 'ON' the ignition lock and check for proper functioning of electrical and ABS system. Incase if the fuse fails again, consult the nearest TVS Motor Company Authorised Main Dealer / Authorised Dealer



Do not use vehicle by shorting the wires without a fuse. This may result in overheating of electrical / wiring and may result in fire. Never replace a fuse with a rating other than that prescribed, in order to avoid damage to the electrical equipment.

Visually inspect the spark plug gap. The gap should be 0.8 to 0.9 mm. If the gap is found to be more than the limit replace the spark plug with a new one.

After cleaning and inspecting the gap, reinstall the spark plug and tighten by hand to avoid cross threading. Finally tighten using the spanner. Do not over tight or cross thread the spark plug.



Caution

Always use only recommended make and type of spark plug. Replace spark plug every 12000 km or 1 year whichever is earlier.

Cover the spark plug hole with a cloth when the plug is removed to prevent entry of dust / water.

It is advisable to tighten the new spark plug by hand till the end, using plug spanner tighten by 1/4 turn. Then loosen the plug by 1/8 turn and re-tighten using plug spanner.

Care should be taken not to damage the spark plug cooling duct (ram air duct) during dismantling / assembling the spark plug.



ENGINE CUMTRANSMISSION OIL

Check the engine cum transmission oil level periodically. The gauge oil level is provided at the right-hand side crankcase cover.

 The check must be performed when engine is in cold condition, after placing the motorcycle in center stand with front wheel touching the ground.



- Place the motorcycle in an upright position on a horizontal and firm surface.
- 3. Wipe-off the surroundings of gauge oil level.
- 4. Remove the gauge oil level and wipe it clean.
- 5. Re-insert the gauge oil level by completely screwing it in.
- Once again remove the gauge and check the oil level

TVS 🛰

- The oil level should be between the minimum and maximum level marks on the gauge as shown in the figure.
- If the oil level is below the minimum level, top up with TVS TRU4 FULLY SYNTHETIC oil (SAE 10W 30 API-SL, JASO MA2) upto the maximum level mark. Do not overfill.
- 9. Wipe out the oil traces with a clean cloth to prevent dust accumulation and re-fix the gauge.



Caution

Do not run the vehicle with insufficient / without engine cum transmission oil as it will cause serious damage to the engine components.

Excessive oil filling will cause oil leak and other malfunctions. Always use TVS TRU4 FULLY SYNTHETIC oil (SAE 10W 30 API-SL, JASO MA2) only.

Make sure that no foreign object gets in the crankcase while topping up the engine oil.



Warning

Correctly recycle or dispose the used engine oil in order to avoid environmental pollution.


CLUTCH ADJUSTMENT

Clutch lever free play is one of the most important adjustment which you may need to check in-between services for better life of the clutch plates.

The free play of the clutch lever should be 8 to 13 mm as measured at the clutch lever end at handle bar (as shown in fig).


If free play is not within the specified limit, adjust the clutch lever free play periodically by means of clutch cable adjuster at arm clutch release.

1. Ensure that the engine is cold (engine oil at room temperature).



TVS >

- 2. Loosen the lock nut (2) while holding the clutch cable adjusting nut (1).
- 3. Adjust the clutch cable adjusting nut (1) 'in' or 'out' to give sufficient play in the clutch lever.
- 4. After adjusting the play, hold the adjuster nut in the same position, tighten the lock nut.





Caution

Too much or too less clutch lever free play will damage the clutch plates, thereby affecting the performance of the vehicle

Adjust the clutch lever free play only when the engine is cold.



A Caution

After adjusting free play properly, if there is a clutch slip or there is difficulty in shifting gear, visit your TVS Motor Company Authorised Main Dealer / Authorised Dealer for rectification

TVS >

REAR SHOCK ABSORBER


TVS Apache RTR 160 4V is provided with dual rated, 7 step adjustable, gas filled rear shock absorber to meet different road and load





During the time of delivery of the motorcycle, the rear suspension is adjusted to the standard configuration.

Rear shock absorber spring stiffness can be set to your convenience. Contact your TVS Motor Company Authorised Main Dealer / Authorised Dealer for setting the rear shock absorber load.





Warning

The rear shock absorber contains highly compressed gas. Do not try to open or disassemble it in any way.



Caution


Adjust step by step. Do not go at a stretch as it will damage the cam.

BRAKES

Front brake

You can observe a master cylinder (1) on the right side of the handle bar, a caliper assembly (2) fitted to the fork leg R along with a wheel speed sensor (3), a disc (4) and the toner ring (5) to the front wheel. Also you can observe a high pressure hose connecting the master cylinder to the HECU of ABS system and another hose connecting HECU to the caliper assembly.

1. Check the master cylinder brake fluid level through the view piece glass (A).





- 2. Brake fluid level always should be above the 'LOWER' mark (B) on the master cylinder when the master cylinder is parallel to the ground.
- 3 If the brake fluid level is below the mark or while applying brake if you feel the brake is more spongy or ineffective due to air entry, contact TVS Motor Company Authorised Main Dealer / Authorised Dealer for topping-up the brake fluid, air bleeding and other brake related inspections.





1 Note


Check the brake fluid level only when the master cylinder is parallel to the ground.



Rear brake - Disc type

You can observe a master cylinder (1) mounted on the right side pillion foot rest, a reservoir (2) below the cover frame R, a caliper assembly (3) fitted on the rear wheel axle, a disc (4) to the rear wheel and a high pressure hose (5) connecting the master cylinder to the caliper.

- 1. Remove the cover frame R (refer page No. 37 for removal procedure).
- 2. Check the brake fluid level in the reservoir. It should be between maximum and minimum level.



3 If the brake fluid level is below minimum or while applying brake if you feel the brake is more spongy or ineffective due to air entry, contact TVS Motor Company Authorised Main Dealer / Authorised Dealer for topping-up the brake fluid, air bleeding and other brake related inspections.






1 Note

Check the brake fluid level only when the master cylinder is parallel to the ground.

Brake pad wear indicator

Visually check the brake pads for wear. If the wear is found beyond the wear indicator groove as shown in the figure then, replace the brake pads as a set with a new one.



Δ

Warning

Lack of maintenance of the brake system increases the risk of accident. If you notice any malfunction in brake system contact nearest TVS Motor Company Authorised Main Dealer / Authorised Dealer.




Caution

Replace the brake pads as a set, if the wear indicator shows beyond the wear limit.



Rear brake - Drum type

- 1. Measure the free play of the rear brake pedal at the pedal end as shown in the figure.
- The free play of the brake pedal before the engagement of brake should be between 15 ~ 20 mm.




⚠ Warning

Check the brake pedal play periodically. However the brake play needs to be adjusted more frequently depending upon the usage.


TVS 🛰

- If the measured free play is more than the limit, adjust the nut provided at the rear wheel end to obtain the correct play.
- Turn the adjuster nut clockwise to reduce the free play or turn it in anti-clockwise direction to increase the free play.



Brake shoe wear indicator

When the brake is applied, the wear index mark (A) on the cam brake should be within the range of wear limit indicator (B) on the rear brake panel assembly. In case of the mark going beyond the wear limit, index the lever to next slot with the help of Dealer to extend shoe life.



Â

Caution

Replace the brake shoes as a set, if the wear limit indicator shows beyond the wear limit even after indexing the lever.



TYRES*

Tyre pressure:

Check the tyre pressure atleast once in a week if not more frequently. Insufficient air pressure in the tyres not only hasten tyre wear, but also seriously affects the stability of the vehicle.

Under-inflated tyres make smooth cornering difficult and over-inflated tyres decreases the tyre contact with the ground which can lead to skidding and loss of control. Be sure that the tyre pressure is within the specified limits at all times.

	Solo	Pillion
Front	1.75 kg/cm² (25 psi)	1.75 kg/cm² (25 psi)
Rear	2.00 kg/cm² (28 psi)	2.25 kg/cm² (32 psi)

⚠ Wa

Warning

The tyre inflation pressure in cold condition and the tyre thread condition are extremely important for the performance and safety of the rider. Check the tyres frequently for inflation pressure as well as the wear pattern on it. Use of a tyre other than the standard will cause instability.

Tyre tread condition

Operating the vehicle with excessively worn tyres will decrease riding stability and can lead to loss of control. It is recommended to replace the tyre when the tyre wears off to the tyre wear indicator level (indicated by TWI on the tyre).



* The pneumatic tyres fitted in this vehicle meet the requirements specified by BIS and comply with the requirements under the Central Motor Vehicles Rules (CMVR), 1989.



While reassembling the tyre, after removing from wheel rim, ensure that the arrow mark (A) provided on the tyre, faces the direction of wheel rotation.

Tyre puncture

TVS Apache RTR 160 4V is fitted with a tubeless tyre on both front and rear wheel. Incase of any puncture / tyre damage it is advised to visit nearest tyre manufacturer Dealer or the tyre repair shops who know the repairing methods of tubeless tyre. It is not necessary to remove the tyre from wheel rim always to attend the puncture. Even though, if there is a need of tyre removal, it is strongly recommended to use a tyre removal / fitment machine.



Caution

Side walls of the tubeless tyres which are in contact with the wheel rim are only seals the air inside the wheel assembly. Hence, care should be taken not to damage the side walls of the tyres during removal / reassembly.

It is advisable to balance the wheels every 1 year or 12000 km and also after every tyre puncture or tyre replacement to have better high speed performance.



If at all, tyre levers need to be used, the levers should be free from sharp edges and care should be taken not to damage the rim and tyre.




Warning

Use of a tyre other than the standard may cause instability and improper function of ABS.

Keep the toner ring upwards whenever the wheel is removed in order to avoid damage to the toner ring. Damaged toner ring affects the ABS function.



Tyre Maintenance Tips



O Note

If vehicle is in hold condition for long time

- Need movement of vehicle to avoid particular spot of tyre not to touch the ground for more than week time.
- Inflation pressure should check on cold condition maximum travel time should not exceed more than 1 km.


• Weekly basis inflation pressure check helps to improve 10% of tread life & fuel efficiency.



DRIVE CHAIN

Proper lubrication and adjustment of drive chain gives long service life of the chain. Poor maintenance of the chain causes premature wear or damage to the drive chain and sprockets. The drive chain must be cleaned, checked, lubricated and adjusted at specified intervals mentioned in the maintenance schedule.

Even though the chain is cleaned, lubricated and adjusted during regular service by the Dealers, the user must clean the chain with a dry cloth and apply TRU SPRAY / TRU4 oil as frequently as every 500 km for better chain life and smooth vehicle running.



Check, clean, lubricate and adjust the drive chain in the following manner:

- Place the vehicle on centre stand with the transmission in neutral.
- Inspect the drive chain slackness (vertical movement) using the finger as shown in the figure.
- 3. The slackness of the drive chain should not exceed the limit (25 ~ 30 mm).
- If the slackness is found more contact TVS Motor Company Authorised Main Dealer / Authorised Dealer for adjustment.
- If the slackness is found within the limit, clean the chain with a dry cloth and lubricate using TRU SPRAY /TRU4 oil.

⚠ Warning

Riding with improperly adjusted chain / high slackness can cause the chain to come off the sprockets resulting in accident or serious damage to the motorcycle.

Misalignment of rear wheel or sprockets can cause abnormal wear of chain and sprockets and results in unsafe riding condition.






Caution

Lubricate the drive chain after the motorcycle is washed with water or riding in rainy / wet condition.

The chain must be serviced more frequently when the vehicle is operated under severe conditions like dusty, muddy, wet, high speed or frequent starting / stopping.

FRONT WHEEL REMOVAL AND REASSEMBLY

- 1. Remove the axle nut (1) along with a washer.
- Pull out the axle (2) along with a washer and remove a spacer from both the sides of the wheel.



- 3. Place a support below the frame to prevent vehicle from falling and lift the vehicle up.
- 4. Carefully dislocate the disc from the caliper assembly and slide the wheel out.
- 5. Reverse the procedure for reassembling.



Warning

Ensure proper seating of disc in the caliper assembly while reassembling the wheel.


Ensure to re-fix the right spacers at both the sides of the wheel.

Keep the toner ring upwards whenever the wheel is removed in order to avoid damages to the toner ring. Damaged toner ring affects ABS function.



REAR WHEEL REMOVAL AND REASSEMBLY - DISCTYPE

- 1. Remove the wheel hugger rear.
- 2. Remove the axle nut (1) and along with the washer and partially pull out the axle (2).
- Take out the caliper assembly by dislocating it from the disc and the swing arm lug.
- Carefully hang the caliper assembly in the swing arm itself. Take out the spacer and pull out the axle fully.
- Remove the wheel assembly by gently tapping it along with the disc.



- During re-assembly, engage the drum sprocket with the wheel along with the drive chain and then assemble the wheel into swing arm.
- Re-assemble the other parts in the reverse order of removal.



Caution

While assembling the caliper assembly ensure that the slot provided in the caliper is properly located to the lug provided in the swing arm assembly.

Always make sure that whenever the wheel is removed, axle nut is properly re-tightened to the specified torque and chain play is re checked and adjusted if required.




Note

During removal of rear wheel axle hold the drum sprocket assembly with the hand as it may fall. Carefully hang the drum sprocket along with chain in the swing arm itself.



- 1. Remove the wheel hugger rear.
- Remove the rear brake adjuster nut (1) and disconnect the brake rod.
- Remove the split pin (2) and the nut (3) from the torque link mounting with the brake panel and disconnect the torque link.
- Remove the axle nut (4). Pull out the axle (5) and take out the spacer bush from the rear wheel assembly.
- Tilt the vehicle to the left and take out the wheel assembly along with brake panel. Separate the brake panel from the wheel.







For locating and reassembling the rear wheel easily, engage the gear. This will arrest the free movement of the drum sprocket. Reverse the procedure for reassembly.



Caution

Once the split pins are removed, replace them with new ones



For storage of your motorcycle for longer periods of over a month and above, we recommend to carry out the following steps:

- Clean the vehicle thoroughly. Park the vehicle on centre stand.
- Warm up the engine and drain engine cum transmission oil. Store the oil, if new, in a dust free container.
- 3. Empty the fuel tank.
- Remove the spark plug and feed in several drop of engine cum transmission oil through spark plug hole. Crank the engine few times and reinstall the spark plug.
- Remove the battery, store it away from direct sunlight and freezing temperatures.




Caution

Do not park the vehicle on a slope or soft ground or else it may fall.

During storage, the battery must be recharged on a constant current battery charger at recommended amperage atleast once in a month.



- Place a suitable support at the bottom of the frame so that both the tyres are off the ground. This will ensure better tyre life.
- 7. Cover up the vehicle completely with a clean tarpaulin or any other suitable cover. Store the vehicle inside a garage or similar area to avoid damage due to dust and rain. Make sure that the storage area is well ventilated and free from any source of flame or spark.



- Take the vehicle out of the garage and clean it thoroughly.
- Remount the battery after bench charging if required.
- Fill the engine cum transmission oil (TVS TRU4 FULLY SYNTHETIC - SAE 10W30 API-SL, JASO MA2) and check the oil level using the gauge.
- 4. Lubricate the parts as instructed in the maintenance schedule.
- 5. Fill up fresh petrol in the fuel tank.
- Check and inflate the tyres to the specified tyre pressure.
- Check and correct the points mentioned in page No. 38.



Caution

Avoid using alkaline solution like detergent soaps for washing. This may damage head lamp and other lamp assemblies.

Turn the ignition switch to 'ON' position. Start the engine and allow it to idle for a few minutes and ride out



RECOMMENDED TIPS WHEN TAKING A LONG TRIP OF MORETHAN 500 KM

- A) Please keep the following items for use in case of emergency:
 - 1. Complete tool kit / first aid kit
 - 2. Recommended spark plug one number.
 - 3. Turn signal lamp bulb one number.
 - 4. Throttle and clutch cables one number each.
- B) Precautions to be taken for the journey:
 - 1. Ensure engine cum transmission oil and brake oil level are up to the level.
 - 2. Adequate fuel in fuel tank.
- C) Check your motorcycle for the following:
 - 1. Tightness of all bolts and nuts with correct torque value.
 - 2. Fitness of tyres / tyre pressure / tread depth.
 - 3. All bulbs, indicators and horn function.
 - 4. Balancing of wheel
 - 5. Check proper functioning of ABS (through ABS warning lamp)
 - 6. Smooth functioning of all cables and their free plays.



- Smoothness of steering operation.
- Slackness and lubrication of chain (page No. 66).
- Front / rear brake functioning and rear brake lamp switch adjustment.
- 10. Front fork for any abnormality.
- 11. Spark plug cleanliness and condition of spark plug.
- 12 Air filter element cleanliness
- 13. Correct idling speed.
- 14 Lubrication of all items mentioned in the periodic maintenance schedule.
- 15. Intactness of EVAP system hoses and canister.
- 16. Any other job as necessary.
- 17. Have your vehicle checked at any TVS Motor Company Authorised Main Dealer / Authorised Dealer.



Ensure the first aid equipments are changed periodically based on the expiry.



Caution

Long journey are to be taken only after the running-in period of 1000 km.



TVS Motor Company Limited ('the Company') give this warranty with respect to the TVS Apache RTR 160 4V manufactured by the Company.

While the Company has taken every care to maintain quality in the manufacture of the TVS Apache RTR 160 4V, the above said warranty is subject to other terms of warranty:

During 5 Years from the date of purchase or during the first 60,000 km of run for the vehicle in the hands of original retail purchaser, whichever is earlier, the parts of the vehicle covered under warranty which prove to the satisfaction of the Company to have a manufacturing defect will be repaired or replaced free of cost.

The Company's obligation under this warranty is limited to repairing or replacing, free of cost, those parts of the vehicle which upon examination by the Company may prove to the Company's satisfaction to have a manufacturing defect, and in such cases the Company's decision either to repair or replace the affected parts will be final. In the event of replacement of parts, the Company also reserves the right to use parts of the same brand as the affected parts or any other brand which is used by the Company in the course of manufacture. All parts replaced under this warranty will become the property of the Company and must be returned to the company.

Limitations of Warranty:

This warranty shall not apply to following condition:

- 1. Any natural wear and tear, including without limitation, aging.
- 2. Warranty claims on proprietary items such as tyres, tubes and batteries etc,. should be preferred by the user directly on the respective manufacturer, as per their warranty terms and the Company shall not be liable in any manner in respect to the same.
- 3. Parts repaired or replaced under this warranty are warranted only throughout the remainder of the original warranty period.
- 4. The Company is not liable for any delay in servicing due to reasons beyond the control of the Company or any of its Authorised Main Dealers / Authorised Dealers.

5. In any event, the Company is not liable for indirect, remote, incidental or consequential damages.



- 6. The Company may make any modification or improvement to vehicles in future production at any time without prior notice and without any obligation to install the same on vehicles previously dispatched for sale.
- 7. Any claim under this warranty will lie only when the customer:
 - takes his vehicle to an Authorised Main Dealer / Authorised Dealer of the Company and reports the
 problem he / she felt in the vehicle to enable the Authorised Main Dealer / Authorised Dealer to inspect
 the same and assess the cause for the reported problems.
 - produces to such Authorised Main Dealer / Authorised Dealer the Service Handbook for the concerned vehicle for verification of relevant details.

8. This is the only warranty given by the Company for the TVS Apache RTR 160 4V. No employee, Dealer or other person is authorised to extend or enlarge this warranty.

⚠ Warning

Modifications to this vehicle not approved by the TVS Motor Company may cause loss of performance and render it unsafe for use and disqualifies for warranty coverage also.

Following Toll Free numbers can be contacted for battery related queries if any.

Incase of EXIDE battery, call :- 1800 103 5454

Incase of AMCO battery, call :- 1800 425 0096

Incase of TATA GREEN battery, call :- 1800 419 8888

Incase of AMARON battery, call :- 1800 425 5858

Following Toll Free numbers can be contacted for Tyre related queries if any.

Incase of TVS Srichakra, call :- 04522443300

Incase of JK tyre, call :- 18002581100

Incase of Maxxis tyre, call :- 1800 532 2888



List of parts not covered under warranty

ITEM	WHAT TO CHECK FOR	
Normal Maintenance operations	Engine tune-up, decarbonizing, fuel system cleaning, oil changes, head light focusing, fastener retightening, ignition timing, clutch and brakes as well as other normal adjustments.	
Wear & tear items	Chain, sprockets, clutch and brake linings, fasteners, shims, washers, oil seals, gaskets, O' rings and spokes etc.	
Electrical	Bulbs , fuse, AHO	
Service Maintenance Parts	Oil filters, spark plug, air filter, SAI filter, oil and brake fluid	
Rubber, rexine & plastic items	All hoses , pipes and plastic aesthetics	
Proprietary Items	Battery, tyres and tubes (the warranty terms are subject to our agreement with proprietary OEM)	
	Parts of the vehicle getting affected due to atmospheric effect / environmental factors (rusting, paint peel off etc.). However, depending on the vehicle usage condition, warranty would be accepted up to 2 years from the date of purchase.	
Others Factors	Parts of the vehicle which have been tampered with, altered, repaired or replaced by persons not authorised by the Company and which in the sole judgement of the Company affect the performance of the vehicle.	
	Parts which are used in conjunction with parts not made or recommended by the Company.	



List of parts not covered under warranty

ITEM	WHAT TO CHECK FOR
	Parts suffering damage or resultant damage by accident, misuse, negligent treatment, use of bad quality lubricants or impure fuel or by omission to follow the guidance and instructions contained in this owner's manual.
Others Factors	Vehicles on which engine number or chassis number is deleted, defaced or altered. Vehicles on which any warranty service including scheduled paid service is not availed when it falls due (at TVS Motor Company Authorised Main Dealer / Authorised Dealer).
	Vehicles sold or transferred by original retail purchaser. Vehicles used for racing or any competition or used otherwise than for ordinary personal transportation. Vehicles attached with side cars etc. Vehicles which have been taken out of India. Vehicles affected by natural calamities like flood, earthquake, tsunami, storm etc,. If the vehicle has been used for commercial purpose like taxi or used for rental or hiring or any other purpose other than regular personal transportation.



SERVICE INFORMATION

There are twenty one services for TVS Apache RTR 160 4V during warranty period. Of these, the first five are free services for which labour charges are free. In addition to these five free services, we have a scheme of sixteen pay services. For keeping the maintenance track of your vehicle, free and pay service record sheets are attached in the Service Handbook given to you during the time of your vehicle purchase. Please have the relevant record sheet filled by the Dealer who is carrying out the maintenance service.

For availing any of the twenty one warranty services, please take your vehicle and your Service Handbook to any of our Authorised Main Dealers or any of our Authorised Dealer. After effecting the service, the Authorised Main Dealer or the Authorised Dealer will affix their stamp on the last column of free or pay service record sheet of Service Handbook for your record and reference.

Periodic maintenance always helps good performance of an automobile and our services are planned to keep your TVS Apache RTR 160 4V performing good. Please note that carrying out the service for your vehicle at scheduled intervals at any of the TVS Motor Company Authorised Main Dealer / Authorised Dealer is necessary for availing of warranty. And please also remember that, after the services are over, periodic servicing of your vehicle at appropriate intervals, depending upon its extent of use, will keep your vehicle at its best level of performance.

In case you need any clarification or assistance, please feel free to write to us mentioning the frame number, engine number and the date of purchase of your vehicle also the name and place of the Authorised Main Dealer / Authorised Dealer from whom you bought the vehicle and getting it serviced.

Service Department
TVS MOTOR COMPANY LIMITED
P.O.Box No. 4, Harita, Hosur - 635 109,
TAMILNADU, INDIA.
Toll free no. :- 1800-258-7111





Drive In. Drive Out.



Say bye-bye to waiting time for servicing your bike.

Get your vehicle serviced in 1 hour at no additional cost. Contact your nearest Dealership for details.

[†]Facility available at selected Dealerships only. Terms and conditions apply





Busy Life? Easy Servicing!

Now, service your bike anywhere, anytime.

- ★ Service the vehicle at your door step.
- * Available for regular maintenance or breakdown service only.
- ★ Offered at nominal convenience charges.

Contact your nearest Dealership for details.

[†]Facility available at selected Dealerships only. Terms and conditions apply





Busy Life? Easy Servicing!

Now, service your bike anywhere, anytime.

- ★ Service the vehicle at your door step.
- ★ Available for regular maintenance or breakdown service only.
- ★ Offered at nominal convenience charges.

Contact your nearest Dealership for details.

[†]Facility available at selected Dealerships only. Terms and conditions apply

TECHNICAL SPECIFICATIONS



MANUFACTURER: TVS MOTOR COMPANY LIMITED

P.B. No1, Bythahalli, Kadakola post, Mysore - 571 311, India.

ENGINE

Type : 4 stroke, oil cooled, single

cvlinder OHC

Cylinder bore : 62 mm Stroke : 52.9 mm

Piston displacement : 159.7 cm^3 Compression ratio : $10.15 \pm 0.3 : 1$

Air filter : Viscous Paper filter

Oil filter : Wire mesh and micronic paper

filter

Lubrication system : Forced wet sump

Maximum power in kW: 12.97 @ 9250 rpm

Maximum torque in Nm: 14.73 @ 7250 rpm

Maximum speed : Around 114 km/h

Engine idling rpm* : 1600 ± 200 rpm

Starting system : Electric starter

Emission norms : BS VI

TRANSMISSION

Clutch : Wet - multiplate type

Gear shift pattern : 1 down and 4 up
Primary transmission : Helical gears

Secondary transmission: Chain and sprockets

GEAR RATIOS

 I gear
 : 2.917

 II gear
 : 1.857

 III gear
 : 1.333

 IV gear
 : 1.050

 V gear
 : 0.880

 Primary reduction
 : 3.095

 Final reduction
 : 3.461

^{*} Under warm condition



CHASSIS

Overall length : 2035 mm
Overall width : 790 mm
Overall height : 1050 mm
Seat height : 800 mm

Ground clearance : 180 mm (unladen)

Wheel base : 1357 mm

Kerb weight (with toolkit: 147 kg (Disc brake version) /

and 90% of fuel) 145 kg (Rear Drum brake version)

Pay load : 130 kg

Maximum laden weight : 277 kg (Disc brake version) /

275 kg (Rear Drum brake version)

Steering angle : 35° (both sides)

Caster angle : 26°

Frame : Double Cradle Split Synchro STIFF

(DCSSS)

Front suspension : Telescopic oil damped

Rear suspension : Gas charged Mono shock absorber,

7 step adjustable with rectangular

swing arm

Trail length : 95.8 mm

TYRE*

Tyre size

Front : 90/90-17 49P Tubeless

Rear : 130/70-17 M/C 62P Tubeless /

130/70 R17 M/C 62P Tubeless /

110/80-17 57P Tubeless

Tyre pressure

Front : 1.75 kg/cm² (25 psi) Rear - solo : 2.00 kg/cm² (28 psi) Rear - dual : 2.25 kg/cm² (32 psi)

BRAKES

Front : Hand operated, 270 mm petal disc Rear : Foot operated, 200 mm petal disc

(Disc Brake version) /

Foot operated, 130 mm dia drum

(Drum Brake version)

* The pneumatic tyres fitted in this vehicle meet the requirements specified by BIS and comply with the requirements under the Central Motor Vehicles Rules (CMVR), 1989.



ELECTRICAL

Type : AC generator

Ignition system : ECU - 3D Ignition timing map

Spark plug : BOSCH - UR4KE

Battery type : 12V, 8 Ah

Generator : Fly wheel magneto 12V, 300W

Head lamp : 12V, LED Headlamp
Position lamp : LED lamps (12V, 3W x 2)

Tail / brake lamp : LED lamps (1W max / 2.5W max)

Turn signal lamp : $12V,10W \times 4$ Number plate lamp : $12V,5W \times 1$

Instrument panel : LCD / LED indicators

Horn : 12V, DC x 2

Fuse : 12V, 25A x 1 (Main fuse)

: 12V, 15A x 1 (ABS fuse) : 12V, 15A x 1 (DC load fuse) : 12V, 10A x 1 (EMS fuse)

CAPACITIES

Fuel tank capacity# : 12 | (including reserve)

Reserve : 2.5 l

Fuel : BS VI / Unleaded Petrol with

minimum RON 91

Engine cum transmission: TVS TRU4 FULLY SYNTHETIC oil

oil grade (SAE 10W30 API-SL, JASO MA2)

Engine cum transmission: 1200 ml (after draining) oil capacity 1400 ml (after disassembly)

Front fork oil grade : TRU Fork oil

Front fork oil capacity : 242 ± 2.5 cc / leg

Brake fluid : TVS Girling DOT 3 / DOT 4



Specifications are subject to change without notice.



Caution

Using the bulb other than the specified rating can result in overloading of the electrical system or premature failure of the bulb. * The fuel tank is not a measuring instrument and the capacity of fuel tank may slightly vary from the indicated capacity.



Dear Customer,


It is mandatory under the Motor Vehicles Act to insure all motor vehicles. No motor vehicle can be used in a public place without a valid policy of insurance issued by an authorised insurer. Driving a motor vehicle without any such insurance is an offense under Motor Vehicles Act.

To assist our Customers on their insurance requirements such as the prompt issue and renewal of policies as well as expeditious settlement of claims if any, our preferred insurers are:











suraksha ka/ naya nazariya















